








SRS
SMD Rework System
Ref.: **SRWS-9SC** 100V
SRWS-1SC 120V
SRWS-2SC 230V




SPARE PARTS	
RWS:	
-TOOL HEIGH ADJ. KNOB:	0017053
-ROTATION ADJ. KNOB:	0017054
-HEIGHT ADJ. KNOB:	0017055
-HOSE CLAMP:	0017056
-SCREW:	0017057
-JT TOOL ADAPTER:	0017058
-TE TOOL ADAPTER:	0017059
PHSK HEATER UNIT:	
-CIRCUIT (230V):	0021106
-CIRCUIT (120V):	0021110
-CIRCUIT (100V):	0021111
-LAMP (230V):	0016585
-LAMP (100V, 120V):	0016586
-GLASS:	0016609
-ENCLOSURES:	
· TOP	0021152
· BOTTOM	0026518

Ref.: **PHSE-9KB** 100V FUSE T-8A
PHSE-1KB 120V FUSE T-8A
PHSE-2KB 230V FUSE T-4A

SPARE PARTS	
JTU CONTROL UNIT:	
-ENCLOSURES:	
· TOP	0019028
· BOTTOM	0026196
· FRONT	0026199
· BACK	0026195
FOR REF. JTSE-1UA:	
-CIRCUIT	0024361
-SUCTION PUMP	0026338
-HOT AIR PUMP	0018769
FOR REF. JTSE-2UA:	
-CIRCUIT	0024360
-SUCTION PUMP	0026337
-HOT AIR PUMP	0018769

Ref.: **JTSE-1UA** 100/120V FUSE T-8A
JTSE-2UA 230V FUSE T-4A



ESHT-A

0027797

0027964