



www.jbctools.com


INSTRUCTION MANUAL



Guide sets for SF280

Ref. GSF08V/GSF10V/GSF15V/
GSF05/GSF08/GSF10/GSF15

Guide Set for SF280 with V-Cut



Packing List

GSF08V - Ø 0,8 mm

Includes:

0018630	Guide tube	1 unit
0018632	Input nozzle	1 unit
0021027	Non-stick nozzle	1 unit
0018637	Guide wheel	1 unit
0018638	Blade clamp	1 unit
0018635	Blade	1 unit
0019818	Manual	1 unit

GSF10V - Ø 1 mm

Includes:


0019168	Guide tube	1 unit
0019170	Input nozzle	1 unit
0020950	Non-stick nozzle	1 unit
0019172	Guide wheel	1 unit
0018638	Blade clamp	1 unit
0018635	Blade	1 unit
0019818	Manual	1 unit

GSF15V - Ø 1,5 mm

Includes:

0019169	Guide tube	1 unit
0019093	Input nozzle	1 unit
0020950	Non-stick nozzle	1 unit
0019296	Guide wheel	1 unit
0018638	Blade clamp	1 unit
0018635	Blade	1 unit
0019818	Manual	1 unit

Guide Set for SF280 without V-Cut



Packing List

GSF05 - Ø 0,5 - 0,6 mm

Includes:

0019521	Guide tube	1 unit
0019520	Input nozzle	1 unit
0021027	Non-stick nozzle	1 unit
0019519	Traction wheel	1 unit
0019479	Counting wheel	1 unit
0019818	Manual	1 unit

GSF08 - Ø 0,7 - 0,8 mm

Includes:

0018630	Guide tube	1 unit
0018632	Input nozzle	1 unit
0021027	Non-stick nozzle	1 unit
0019480	Traction wheel	1 unit
0019479	Counting wheel	1 unit
0019818	Manual	1 unit

GSF10 - Ø 0,9 - 1 mm

Includes:

0019168	Guide tube	1 unit
0019170	Input nozzle	1 unit
0020950	Non-stick nozzle	1 unit
0019480	Traction wheel	1 unit
0019479	Counting wheel	1 unit
0019818	Manual	1 unit

GSF15 - Ø 1,2 - 1,5 mm


Includes:

0019169	Guide tube	1 unit
0019171	Input nozzle	1 unit
0020950	Non-stick nozzle	1 unit
0019481	Traction wheel	1 unit
0019479	Counting wheel	1 unit
0019818	Manual	1 unit


Changing the drag wheels and the blade

For this operation, disconnect the unit.

1. Use the allen key and the spanner to loosen the screws.



2. Replace the wheel, the blade clamp and the blade with the new ones.




 * Handle with care to avoid any cuts with the blade because it is sharp.

Replacing the guide tube

For this operation, disconnect the tool from the control unit.

1. Open the guide clamp, take off the guide tube and insert the new one.




2. Adjust the length of the tube by opening the guide clamp. Once it is fixed, put the non-stick nozzle.



Tool assembly


Connect the tool to the control unit.

1. Push the guide tube to the end and tighten the screw.
2. Connect the jack.



Load the solder wire

1. Use the lock rings to prevent the reel from sliding on the bar.
2. Feed the wire into the input nozzle (2) until it reaches the wheels.



3. Press the button on the tool or the wire-load button on the station.

4. Make sure the wire passes through the nozzle.

Notes

[illegible]

Specifications

GSF08V - Ø 0,8 mm with V-Cut
GSF10V - Ø 1 mm with V-Cut
GSF15V - Ø 1,5 mm with V-Cut
GSF05 - Ø 0,5 - 0,6 mm without V-Cut
GSF08 - Ø 0,7 - 0,8 mm without V-Cut
GSF10 - Ø 0,9 - 1 mm without V-Cut
GSF15 - Ø 1,2 - 1,5 mm without V-Cut

- Weight: 102 gr (0.01 lb)
- Guide tube length: 126 cm (49.6 in)

Complies with CE standards.
ESD protected.

JBC

Warranty

JBC's two-year warranty covers this equipment against all manufacturing defects, including the replacement of defective parts and labour. Warranty does not cover product wear or misuse. In order for the warranty to be valid, equipment must be returned, postage paid, to the dealer where it was purchased.

Register your warranty within 30 days of purchase
in www.jbctools.com/productregistration



This product should not be thrown in the garbage.

In accordance with the European directive 2002/96/EC, electronic equipment at the end of their life must be collected and returned to an authorized recycling facility.



Manual in other languages available on our website

www.jbctools.com